

## **Material and Equipment Recommendations**

## (Material coverage is approximate)

## **MATERIALS**

RPM mats 1 mat (20"W x 44"L) covers 6.11 s/f

RPM-330 5/16" stud height RPM-500 1/2" stud height

RPM grommets 100 per bag, 100 s/f per bag, depending on quantity of wire turns

Adhesive To adhere RPM mats to substrate

Over Plywood Roberts 2001 (felt-back sheet vinyl adhesive) or equivalent

60 s/f per gallon with 1/8" x 1/8" v-notch trowel

Over Concrete Bostik's Hydroment Ultra Set Advanced (urethane adhesive)

50 s/f per gallon with 1/8" x 1/8" v-notch trowel

Electric Heat Wire Depends on size of project, ask your distributor

Bonding Agent Apply to RPM mats after installing wire, prior to cement leveler

See manufacturers recommendation for coverage

Underlayment Trowelable cement leveler or self leveling underlayment.

Coverage: RPM-330 (5/16") / 2.13 lbs per s/f. RPM-500 (1/2") / 3.40 lbs per s/f.

## **EQUIPMENT**

Stapler/Staples To attach RPM to plywood/OSB after adhesive

Upholstery Stapler Porter Cable Model # US58 Pneumatic Upholstery Stapler or equivalent

Porter Cable US12G Galv. Upholstery Staples 3/8 x 1/2, 600 s/f per box

or Crown Stapler 1/4" Narrow Crown Stapler with depth control

1/4"W x 1/2" - 3/4"D Galv. Crown Staples

Compressor For stapler

Knee Pads For kneeling on RPM mats

Gloves For stringing wire and for when you are on hands/knees on RPM mats

Safety Glasses Always recommended

Chalk Line For snapping lines to ensure straight installation

Bucket(s)/Water For cement mixing and cleanup

Sponge For keeping trowel clean during adhesive application

Drill For cement mixing
Mixing paddle To mix the cement leveler
1/8" x 1/8" V-Notch Trowel To apply adhesive

1/8" x 1/8" V-Notch Trowel To apply adhesive Metal Flat Trowel To screed leveler

Wood Float To press RPM down into adhesive (or use metal trowel)

Utility Knife For cutting RPM

Glue Gun/Glue Sticks
To attach to cold lead and end splice of heat wire
Pump Sprayer
To apply bonding agent (preferred method)

Foxtail Brush To brush out puddled areas of (or apply) bonding agent

RPM GT Pro Grommet Tool To install RPM grommets